Oki Data CONFIDENTIAL

OKIOFFICE84/OKIFAX4500
RSPL

Related drawings

Drawing No.	Name
40672201TH	FAX NIP-FX051(120V) Maintenance Manual
40672201TL	FAX NIP-FX051(120V) Disassembly Drawing

Bom	Use for	Certification Body	

Rev	Date	DCO No.	Contents	Design	Approval
9	2007-08-28	SP7-3638	Specified substitution	Hidenori Ueda	Hideki Enomoto
10	2008-07-16	SP9-0126	Change Format(Epsilon)	Yumiko Tutumi	Yasuhiro Kaede

Approval	Design	Name
Hideyuki Kondo	Miya Katsuki	FAX NIP-FX051(120V) Recom.spare part.lst
Check		
Date: 1998-05-15	Oki Data Corporation	Drawing No.: 40672201TR

Applicable

Part No.	Printer Series	Destination	Voltage	Model No.	Note
41756201					
41756202					
41756203					
41756301					
41756304					
41756305					
41756306					
41756307					
41756308					
41756309					
41756310					

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year per 500	per 1000	per 2000	Remarks	Special	Del/ Add	ks for environment
	CABINET ASSEMBLY(FAX NIP-FX051)	1	40672601	Unit-Printer(A) (120V)	1	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX051)	2	PA4083-1230G001	HOLDER ASSY	1	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX051)	3	YA4116-1228G001	LED HEAD GENERAL SPEC. 31B	1	1	2	4				-
	CABINET ASSEMBLY(FAX NIP-FX051)	4	41016104	Cable-Flat-Assy	1	5	10	20	For Thai production			-
	~~CABINET ASSEMBLY(FAX NIP-FX051)~~	4	~~YX4083-1134G001~~	~~CABLE FLAT ASSY~~	~~1~~	~~5~~	~~10~~	~~20~~			D	-
	CABINET ASSEMBLY(FAX NIP-FX051)	6	40709907	EP Unit Spec.	1	-	-	-	Consumable			-
	CABINET ASSEMBLY(FAX NIP-FX051)	8a	40588801	DC POWER SUPPLY UNIT(120V)	1	5	10	20				-
	CABINET ASSEMBLY(FAX NIP-FX051)	8b	40588901	DC POWER SUPPLY UNIT(230V)	1	5	10	20				-
	~~CABINET ASSEMBLY(FAX NIP-FX051)~~	~~9~~	~~40687601~~	~~Board-R51~~	~~1~~	~~3~~	~~6~~	~~12~~			D	-
	CABINET ASSEMBLY(FAX NIP-FX051)	9a	42163202	Board- R52-2	1	3	6	12	OEL/Bosch For Thai production			-
	CABINET ASSEMBLY(FAX NIP-FX051)	9b	42163203	Board- R52-3	1	3	6	12	ODA/INT/NO-EC/eFax2000BT/ Lanier4150AG For Thai production			-
	CABINET ASSEMBLY(FAX NIP-FX051)	9c	42163204	Board- R52-4	1	3	6	12	CHN For Thai production			-
	CABINET ASSEMBLY(FAX NIP-FX051)	9d	41821501	Board-R51-2 spare parts collected spec.	1	3	6	12	OEL/Bosch For UK Production			-
	CABINET ASSEMBLY(FAX NIP-FX051)	9e	41821502	Board-R51-3 spare parts collected spec.	1	3	6	12	ODA/INT/NO-EC/eFax2000BT/ Lanier4150AG For UK production			-
	CABINET ASSEMBLY(FAX NIP-FX051)	9f	41821503	Board-R51-4 spare parts collected spec.	1	3	6	12	CHN For UK production			-
	CABINET ASSEMBLY(FAX NIP-FX051)	10a	40044501	Board-UNC	1	3	6	12	ODA/Lanier4150AG			-
	CABINET ASSEMBLY(FAX NIP-FX051)	10b	40044303	Board-WN5	1	3	6	12	CHN/NO-EC			-
	~~CABINET ASSEMBLY(FAX NIP-FX051)~~	~~10e~~	~~40044101~~	~~Board-DN5~~	~~1~~	~~3~~	~~6~~	~~12~~	~~UKF~~		D	-
	~~CABINET ASSEMBLY(FAX NIP-FX051)~~	~~10d~~	~~40044101~~	~~Board-DN5~~	~~1~~	~~3~~	~~6~~	~~12~~	~~GER~~		D	-
	CABINET ASSEMBLY(FAX NIP-FX051)	10e	40044307	Board-WN5	1	3	6	12	INT(AUS)			-
	CABINET ASSEMBLY(FAX NIP-FX051)	10f	41777401	Board-TB0	1	3	6	12	Europe			-
	CABINET ASSEMBLY(FAX NIP-FX051)	10g	40044305	Board-WN5	1	3	6	12	INT-SIN			-
	CABINET ASSEMBLY(FAX NIP-FX051)	10h	40044314	Board-WN5	1	3	6	12	OLA			-
	CABINET ASSEMBLY(FAX NIP-FX051)	11	40605601	H.V. Board P6L	1	5	10	20				-
	CABINET ASSEMBLY(FAX NIP-FX051)	13	40672901	Plate Assy.-Base(A)	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	14	40023901	Bracket-Package	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	15	40236401	Plate Assy.-Shield(HV)	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	17	41767002	Frame Assy.-Scanner L	1	3	6	12	300dpi			-
	CABINET ASSEMBLY(FAX NIP-FX051)	18a	41766702	Frame Assy.-Scanner(U)	1	3	6	12	120V			-
	CABINET ASSEMBLY(FAX NIP-FX051)	18b	41766703	Frame Assy.-Scanner(U)	1	3	6	12	230V			-
	CABINET ASSEMBLY(FAX NIP-FX051)	19	40078401	Unit-048 OPE Panel	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	21a	40606501	Cover-Main(A)	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	21b	40606502	Cover-Main(A)	1	3	6	12	Bosch			-
	CABINET ASSEMBLY(FAX NIP-FX051)	22a	40025301	Cover-Front	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	22b	40025302	Cover-Front	1	3	6	12	Bosch			-
	CABINET ASSEMBLY(FAX NIP-FX051)	24a	40606601	Cover-Rear(A)	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	24b	40606602	Cover-Rear(A)	1	3	6	12	Bosch			-
	CABINET ASSEMBLY(FAX NIP-FX051)	25a	40672801	Cover Assy.-Top(A)	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	25b	40672802	Cover Assy.-Top(A)	1	3	6	12	Bosch			-
	CABINET ASSEMBLY(FAX NIP-FX051)	26	40026101	Spring-TC	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	27	40024001	Guide-Paper(U)	1	3	6	12				-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year per 500	per 1000	per 2000	Remarks	Special	Del/ Add	ks for environment
	CABINET ASSEMBLY(FAX NIP-FX051)	28	PP4083-6168P001	HEAD SPRING	2	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	29	40024101	Guide-Paper(L)	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	31	PB4013-3102P001	B SCREW	10	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX051)	32	PB3529-5116P001	B SCREW FA	10	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX051)	33	PB4013-3102P002	B SCREW B	2	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX051)	34	PB4013-3100P008	Cup Screw B	4	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX051)	35	P3-4HH	Screw	1	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX051)	36	40773601	Sheet-Shield(LED)	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	39	40140801	Bracket-Damper	1	3	6	12				-
	~~CABINET ASSEMBLY(FAX NIP-FX051)~~	~~40~~	~~40148201~~	~~Gear-Damper~~	~~1~~	~~3~~	~~6~~	~~12~~			D	-
	CABINET ASSEMBLY(FAX NIP-FX051)	40	42596601	Damper-Oil	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	41a	40025701	Tray-Document	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	41b	40025702	Tray-Document	1	3	6	12	Bosch			-
	CABINET ASSEMBLY(FAX NIP-FX051)	42a	40025801	Tray-Paper	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	42b	40025802	Tray-Paper	1	3	6	12	Bosch			-
	CABINET ASSEMBLY(FAX NIP-FX051)	43a	40375801	Stacker Assy.-Document	1	3	6	12				-
	CABINET ASSEMBLY(FAX NIP-FX051)	43b	40375802	Stacker Assy.-Document	1	3	6	12	Bosch			-
	CABINET ASSEMBLY(FAX NIP-FX051)	44	T2P3-8C	Screw	2	-	-	-				-
	CABINET ASSEMBLY(FAX NIP-FX051)	50	NB3201-1211P001	CARRIER SHEET	1	-	-	-	GER,Bosch			-
	CABINET ASSEMBLY(FAX NIP-FX051)	51	223A7010P0003	TM-6-DC1	1	-	-	-	GER,Bosch			-
	CABINET ASSEMBLY(FAX NIP-FX051)	54	40332701	Label-Manual slot	1	3	6	12	For OKIOFFICE84			-
	UNIT-PRINTER	1	40592001	Printer Unit Assy	1	-	-	-				-
	UNIT-PRINTER	5	40607401	H.V. Board P2H	1	5	10	20				-
	UNIT-PRINTER	6	40413401	Cover-HV	1	3	6	12				-
	UNIT-PRINTER	7	PB4083-2500P010	TAPPING SCREW B1	2	-	-	-				-
	UNIT 051 OPE PANEL	1a	41766901	OP Panel Assy.-Partial	1	3	6	12	Except Lanier and Bosch			-
	~~UNIT 051 OPE PANEL~~	~~1a~~	~~40712201~~	~~OP Panel Assy.-051 Partial~~	~~1~~	~~3~~	~~6~~	~~12~~	~~ODA/OKI/OEL~~		D	-
	UNIT 051 OPE PANEL	1b	41766904	OP Panel Assy.-Partial	1	3	6	12	Lanier			-
	~~UNIT 051 OPE PANEL~~	~~1b~~	~~40712203~~	~~OP Panel Assy.-051 Partial~~	~~1~~	~~3~~	~~6~~	~~12~~	~~Lanier~~		D	-
	UNIT 051 OPE PANEL	1c	40712204	OP Panel Assy.-051 Partial	1	3	6	12	Bosch			-
	UNIT 051 OPE PANEL	2a	40682801	Sheet-Function	1	3	6	12	INT/OEL			-
	~~UNIT 051 OPE PANEL~~	~~2a~~	~~00073313~~	~~Sheet-F-051~~	~~1~~	~~3~~	~~6~~	~~12~~	~~(TBD)OKI/OEL~~		D	-
	UNIT 051 OPE PANEL	2b	00073312	Sheet-F-051	1	3	6	12	French(TBD)			-
	UNIT 051 OPE PANEL	2c	00073311	Sheet-F-051	1	3	6	12	German(TBD)			-
	UNIT 051 OPE PANEL	2d	00073301	Sheet-F-051	1	3	6	12	Italian(TBD)			-
	UNIT 051 OPE PANEL	2e	00073302	Sheet-F-051	1	3	6	12	Norwegian(TBD)			-
	UNIT 051 OPE PANEL	2f	00073303	Sheet-F-051	1	3	6	12	Danish(TBD)			-
	UNIT 051 OPE PANEL	2g	00073304	Sheet-F-051	1	3	6	12	Swedish(TBD)			-
	UNIT 051 OPE PANEL	2h	00073305	Sheet-F-051	1	3	6	12	Dutch(TBD)			-
	UNIT 051 OPE PANEL	2i	00073307	Sheet-F-051	1	3	6	12	Spanish(TBD)			-
	UNIT 051 OPE PANEL	2j	40682802	Sheet-Function	1	3	6	12	ODA			-
	~~UNIT 051 OPE PANEL~~	~~2j~~	~~00073320~~	~~Sheet-F-051~~	~~1~~	~~3~~	~~6~~	~~12~~	~~(TBD)ODA~~		D	-
	UNIT 051 OPE PANEL	2l	40023414	Sheet-F-048	1	3	6	12	Bosch(TBD)			-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year per 500	per 1000	per 2000	Remarks	Special	Del/ Add	ks for environment
	UNIT 051 OPE PANEL	3a	40712701	Sheet-One Touch	1	10	20	40	ODA/INT/OEL/ Lanier4150AG			-
	~~UNIT 051 OPE PANEL~~	~~3a~~	~~00073413~~	~~Sheet-O-051~~	~~1~~	~~10~~	~~20~~	~~40~~	~~(TBD)ODA/OKI/ OEL~~		D	-
	UNIT 051 OPE PANEL	3b	00073412	Sheet-O-051	1	3	6	12	French(TBD)			-
	UNIT 051 OPE PANEL	3c	00073411	Sheet-O-051	1	3	6	12	German(TBD)			-
	UNIT 051 OPE PANEL	3d	00073401	Sheet-O-051	1	3	6	12	Italian(TBD)			-
	UNIT 051 OPE PANEL	3e	00073402	Sheet-O-051	1	3	6	12	Norwegian(TBD)			-
	UNIT 051 OPE PANEL	3f	00073403	Sheet-O-051	1	3	6	12	Danish(TBD)			-
	UNIT 051 OPE PANEL	3g	00073404	Sheet-O-051	1	3	6	12	Swedish(TBD)			-
	UNIT 051 OPE PANEL	3h	00073405	Sheet-O-051	1	3	6	12	Dutch(TBD)			-
	UNIT 051 OPE PANEL	3i	00073407	Sheet-O-051	1	3	6	12	Spanish(TBD)			-
	UNIT 051 OPE PANEL	3j	00073416	Sheet-O-051	1	3	6	12	Bosch(TBD)			-
	UNIT 051 OPE PANEL	4	40023601	Sheet-Cover	1	5	10	20				-
	OPE PANEL ASSEMBLY	1	40022801	Case-OPE(T)	1	-	-	-				-
	OPE PANEL ASSEMBLY	2	40086701	Board-O4W	1	3	6	12				-
	OPE PANEL ASSEMBLY	3	40023001	Holder-LCD	1	-	-	-				-
	OPE PANEL ASSEMBLY	4	40023101	Button-Function	1	-	-	-				-
	OPE PANEL ASSEMBLY	5	PP4120-1067P001	TEN KEY	1	3	6	12				-
	OPE PANEL ASSEMBLY	6a	40023201	Button-Start	1	3	6	12	OKI,Bosch			-
	OPE PANEL ASSEMBLY	6b	40023202	Button-Start	1	3	6	12	LANIER			-
	OPE PANEL ASSEMBLY	7a	40023301	Button-Stop	1	3	6	12	OKI,Bosch			-
	OPE PANEL ASSEMBLY	7b	40023302	Button-Stop	1	3	6	12	LANIER			-
	OPE PANEL ASSEMBLY	9	YB4134-1009P001	LCD	1	3	6	12				-
	OPE PANEL ASSEMBLY	10	PB3529-5116P001	B SCREW FA	2	-	-	-				-
	OPE PANEL ASSEMBLY	11	PB4120-1113P001	RUBBER CONNECTOR	2	3	6	12				-
	FRAME ASSEMBLY-SCANNER L	1	40711801	Frame Assy.-Scanner(L) Partial	1	-	-	-				-
	FRAME ASSEMBLY-SCANNER L	2	40019401	Lever-PC1	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER L	3	40019501	Lever-PC2	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER L	4	40019601	Roller Assy.-ADF	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER L	5	40020201	Plate-Earth ADF	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER L	6	40020601	Piece-Exit	2	6	12	24				-
	FRAME ASSEMBLY-SCANNER L	7	40020703	Spring-Exit	2	6	12	24				-
	FRAME ASSEMBLY-SCANNER L	8	40127501	CONN Cord-Speaker	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER L	9	40141401	Contact Image Sensor	1	3	6	12	300dpi			-
	FRAME ASSEMBLY-SCANNER L	10	40644701	Film-Guide(CIS)	2	3	6	12				-
	FRAME ASSEMBLY-SCANNER L	12	40043301	Plate-Scanner(L)	1	-	-	-				-
	FRAME ASSEMBLY-SCANNER L	13	40019801	Plate Assy.-Scanner(R)	1	-	-	-				-
	FRAME ASSEMBLY-SCANNER L	14	40020301	Gear-Z95/14	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER L	15	40020501	Spring-Latch	2	6	12	24				-
	FRAME ASSEMBLY-SCANNER L	16	40019701	Plate Assy.-Scanner(B)	1	-	-	-				-
	FRAME ASSEMBLY-SCANNER L	17	PB3529-5116P001	B SCREW FA	8	-	-	-				-
	FRAME ASSEMBLY-SCANNER L	18	40153801	Spring-Reinforcement	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER L	19	40025201	Gear-Z38	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER L	20	40024501	Spring-CIS	1	3	6	12				-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	ks for environment
						per 500	per 1000	per 2000				
	FRAME ASSEMBLY-SCANNER L	21	41667901	Plate-Earth_CIS	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER L	22	41734401	Foam-Shielding	2	3	6	12				-
	FRAME ASSEMBLY-SCANNER L	23	40899901	Spring-Reinforcement_add_work	1	3	6	12				-
	PLATE ASSEMBLY-SCANNER (B)	1	40024401	Plate-Scanner(B)	1	-	-	-				-
	PLATE ASSEMBLY-SCANNER (B)	3	40135301	Photo-Interrupter	2	6	12	24				-
	PLATE ASSEMBLY-SCANNER (R)	1	40024601	Plate-Scanner(R)	1	-	-	-				-
	PLATE ASSEMBLY-SCANNER (R)	2	YB4120-1036P001	S MOTOR-151/175	1	3	6	12				-
	PLATE ASSEMBLY-SCANNER (R)	3	PB3529-5116P001	B SCREW FA	2	-	*	-				-
	FRAME ASSEMBLY-SCANNER (U)	1	40711701	Frame Assy.-Scanner(U) Partial	1	-	-	-				-
	FRAME ASSEMBLY-SCANNER (U)	2	PP3527-5153P001	BACK-UP PLATE	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER (U)	3	40267001	Separator Assy.-ADF	1	5	10	20				-
	FRAME ASSEMBLY-SCANNER (U)	5	40021401	Spring-Pinch(L)	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER (U)	6	40021501	Spring-Pinch(R)	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER (U)	7	40745801	Guide-Sensor(A)	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER (U)	8	40021701	Guide-Sensor(B)	2	6	12	24				-
	FRAME ASSEMBLY-SCANNER (U)	9	40481101	Spring-ADF(048)	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER (U)	10	40199101	Cord-Earth	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER (U)	11	PB3529-5116P001	B SCREW FA	2	-	-	-				-
	FRAME ASSEMBLY-SCANNER (U)	12	40021202	Roller Assy.-Sensor	1	5	10	20				-
	FRAME ASSEMBLY-SCANNER (U)	13	40022001	Bearing-S	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER (U)	14	40020801	Gear-Z31	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER (U)	15	40021301	Plate-Support	1	-	-	-				-
	FRAME ASSEMBLY-SCANNER (U)	16	40026301	Bar-Discharge	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER (U)	17	40461301	Film-Exit(DOC)	1	3	6	12				-
	FRAME ASSEMBLY-SCANNER (U)	19	1051002C0001	TR-13-7-6	1	-	-	-	Except ODA			-
	FRAME ASSEMBLY-SCANNER (U)	20	41592101	Tape-Insulation	1	3	6	12	L=200mm			-
	COVER ASSEMBLY-TOP	1	40022201	Cover-Top	1	-	-	-				-
	COVER ASSEMBLY-TOP	2	40606701	Holder-LED(A)	1	3	6	12				-
	COVER ASSEMBLY-TOP	3	40022401	Guide-Document(L)	1	-	-	-				-
	COVER ASSEMBLY-TOP	4	40022501	Guide-Document(R)	1	-	-	-				-
	COVER ASSEMBLY-TOP	5	40022601	Spring-D	1	3	6	12				-
	COVER ASSEMBLY-TOP	6	PP4128-1268P001	PLATE EXIT	2	6	12	24				-
	COVER ASSEMBLY-TOP	7	PP4083-2024P001	EJECT ROLLER A	2	6	12	24				-
	COVER ASSEMBLY-TOP	8	PP4083-2328P003	PINION GEAR B	1	3	6	12				-
	COVER ASSEMBLY-TOP	9	PB4013-3501P003	CS-RING(CS4-SUS)	1	-	-	-				-
	COVER ASSEMBLY-TOP	10	PB3529-5116P001	B SCREW FA	2	-	-	-				-
	PLATE ASSEMBLY-BASE	1	40606801	Plate-Base(A)	1	-	-	-				-
	PLATE ASSEMBLY-BASE	2	PB4016-1960P004	RUBBER FOOT	1	-	-	-				-
	PLATE ASSEMBLY-BASE	3	40606901	Sheet-Insulation(A)	1	3	6	12				-
	PLATE ASSEMBLY-BASE	4	40128001	Cord-Flat(FUJI CARD)	1	5	10	20				-
	PLATE ASSEMBLY-BASE	5	40197001	Sheet-FG	1	-	-	-				-
	PRINTER BESE FRAME UNIT	1	40593201	Frame Unit Assy	1	3	6	12				-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	ks for environment
						per 500	per 1000	per 2000				
	PRINTER BESE FRAME UNIT	3	PP4083-1191P001	SENSOR PAPER E	2	6	12	24				-
	PRINTER BESE FRAME UNIT	4	40721301	Separator Assy	1	3	6	12				-
	PRINTER BESE FRAME UNIT	6	40781701	Spring Compression S	1	3	6	12				-
	PRINTER BESE FRAME UNIT	7	PA4083-1193G001	SENSOR ASSY TONER	1	3	6	12				-
	PRINTER BESE FRAME UNIT	8	40496401	Motor-Pulse	1	3	6	12				-
	PRINTER BESE FRAME UNIT	9	40592401	EP Unit	1	-	-	-	Consumable			-
	PRINTER BESE FRAME UNIT	10	40592601	Toner Cartridge Unit	1	-	-	-	Consumable			-
	PRINTER BESE FRAME UNIT	11	40779601	Roller Hopping	1	3	6	12				-
	PRINTER BESE FRAME UNIT	12	PP4083-1128P001	HOLDER ROLLER H	1	3	6	12				-
	PRINTER BESE FRAME UNIT	13	PB4083-1127P001	MAGNET H.	1	3	6	12				-
	PRINTER BESE FRAME UNIT	14	PA4083-1133G001	SHAFT HOPPING ASSY	1	3	6	12				-
	PRINTER BESE FRAME UNIT	15	NK2-10-SUS	KNOCK PIN	1	3	6	12				-
	PRINTER BESE FRAME UNIT	16	PP4083-1143P001	GEAR IDLE R	1	3	6	12				-
	PRINTER BESE FRAME UNIT	17	PP4083-1184P001	IDLE GEAR 2R	1	3	6	12				-
	PRINTER BESE FRAME UNIT	18	PP4083-1142P001	GEAR R	1	3	6	12				-
	PRINTER BESE FRAME UNIT	19	PP4083-1181P001	GEAR IDLE M	1	3	6	12				-
	PRINTER BESE FRAME UNIT	20	PP4083-1189P001	PLATE EARTH A	1	3	6	12				-
	PRINTER BESE FRAME UNIT	21	PP4083-1188P001	PLATE SIDE M	1	3	6	12				-
	PRINTER BESE FRAME UNIT	22	PP4083-1182P001	GEAR IDLE P	2	6	12	24				-
	PRINTER BESE FRAME UNIT	23	40721001	Gear-Idle-3R	1	3	6	12				-
	PRINTER BESE FRAME UNIT	24	PP4083-1165P001	PLATE TENSION	1	3	6	12				-
	PRINTER BESE FRAME UNIT	25	PP4083-1185P001	GEAR IDLE HEAT	1	3	6	12				-
	PRINTER BESE FRAME UNIT	26	PP4083-1186P001	GEAR IDLE EA	1	3	6	12				-
	PRINTER BESE FRAME UNIT	27	PP4083-1187P001	GEAR IDLE EB	1	3	6	12				-
	PRINTER BESE FRAME UNIT	28	PP4083-1170P001	SHAFT DRIVE E	1	3	6	12				-
	PRINTER BESE FRAME UNIT	29	40074601	Roller Eject	2	6	12	24				-
	PRINTER BESE FRAME UNIT	30	PP4083-1141P001	BEARING REGIST	5	15	30	60				-
	PRINTER BESE FRAME UNIT	31	PB4083-1140P001	ROLLER REGIST	1	3	6	12				-
	PRINTER BESE FRAME UNIT	32	41802101	Film-Guide_F	1	3	6	12				-
	PRINTER BESE FRAME UNIT	33	40737801	Gear-T	1	3	6	12				-
	PRINTER BESE FRAME UNIT	34	40713601	Roller-Transfer	1	3	6	12				-
	PRINTER BESE FRAME UNIT	35	PP4083-1136P001	SPRING PRESSURE L	1	3	6	12				-
	PRINTER BESE FRAME UNIT	36	PP4083-1161P001	BEARING BU	2	6	12	24				-
	PRINTER BESE FRAME UNIT	37	40594601	Roller Pressure B	1	3	6	12				-
	PRINTER BESE FRAME UNIT	38	PP4083-1233P001	GUIDE PAPER R	1	3	6	12				-
	PRINTER BESE FRAME UNIT	39	PP4083-1232P001	GUIDE PAPER L	1	3	6	12				-
	PRINTER BESE FRAME UNIT	40	PP4083-1231P001	HOLDER PAPER	1	3	6	12				-
	PRINTER BESE FRAME UNIT	41	PP4083-1192P001	SENSOR PAPER EXIT	1	3	6	12				-
	PRINTER BESE FRAME UNIT	42	41802001	Spring-Hopper_F	1	3	6	12				-
	PRINTER BESE FRAME UNIT	43	40638001	Contact-CB	1	3	6	12				-
	PRINTER BESE FRAME UNIT	44	40638102	CONN Cord-HV	1	3	6	12				-
	PRINTER BESE FRAME UNIT	45	PB4083-2500P010	TAPPING SCREW B1	3	-	-	-				-
	PRINTER BESE FRAME UNIT	46	40625401	Fan	1	3	6	12				-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Special	Del/ Add	ks for environment
						per 500	per 1000	per 2000				
	PRINTER BESE FRAME UNIT	47	PP4083-1137P001	SPRING PRESSURE R	1	3	6	12				-
	PRINTER BESE FRAME UNIT	49	40562401	Guide Sheet	1	3	6	12				-
	~~PRINTER BESE FRAME UNIT~~	~~51a~~	~~40592801~~	~~Heat Assy~~	~~1~~	~~5~~	~~10~~	~~20~~	~~120V~~		D	-
	PRINTER BESE FRAME UNIT	51a	41982501	Heat Assy	1	5	10	20	120V DCO-SQ1-1709			-
	~~PRINTER BESE FRAME UNIT~~	~~51b~~	~~40592802~~	~~Heat Assy~~	~~1~~	~~5~~	~~10~~	~~20~~	~~230V~~		D	-
	PRINTER BESE FRAME UNIT	51b	41982502	Heat Assy	1	5	10	20	230V DCO-SQ1-1709			-
	PRINTER BESE FRAME UNIT	52	40034001	SPRING STOPPER	1	3	6	12				-
	PRINTER BESE FRAME UNIT	53	PB4091-6047P001	CAUTION LABEL T	1	3	6	12	230V			-
	PRINTER BESE FRAME UNIT	54	40688601	Washer-TR	1	3	6	12				-
	PRINTER BESE FRAME UNIT	55	40710301	Guide-Gear T	1	3	6	12				-
	PRINTER BESE FRAME UNIT	56	40634701	Bearing-Gear	1	3	6	12				-
	PRINTER HEAT ASSY.	1	PB4083-1202P001	ROLLER HEAT	1	5	10	20				-
	PRINTER HEAT ASSY.	2a	41524001	Lamp-Halogen	1	5	10	20	120V			-
	PRINTER HEAT ASSY.	2b	41524002	Lamp-Halogen	1	5	10	20	230V			-
	PRINTER HEAT ASSY.	3	PB4083-1204P001	THERMOSTAT	1	5	10	20				-
	PRINTER HEAT ASSY.	4	PB4083-1205P001	THERMISTOR	1	5	10	20				-
	PRINTER HEAT ASSY.	5	PB4083-1213P001	CORD HEAT	1	5	10	20				-
	CABLES	1	40635401	CONN Cord-Wire(AC)	1	3	6	12				-
	CABLES	2	40040001	CONN Cord-Wire(OPE)	1	3	6	12				-
	CABLES	3	40040201	CONN Cord-Wire(CIS)	1	3	6	12				-
	CABLES	4	40040301	CONN Cord-Wire(PC1/2)	1	3	6	12				-
	CABLES	5	105A1070C0003	TFC-20-10-10	1	3	6	12	CIS-R51			-
	CABLES	6	105A1070C0004	TFC-23-11-14	1	3	6	12	CPE-R51			-
	CABLES	7	105A1073C4002	SSC-40-12	1	3	6	12	HV-R51			-
	CABLES	9	1051003C0001	FPC-25-20	1	3	6	12	LED-R51			-
	CABLES	12	YS4111-5581P001	CORD(TEL1-TEL2)	1	3	6	12	GER,Bosch only			-
	CABLES	14	105A1068C1004	SFC-8	1	3	6	12	For TEL/LINE Cord use			-
	CABLES	15	40687701	Cord-Flat (SUMI CARD)	1	3	6	12	P6L-R51			-